

Presentation Agenda

- · Types of Healthcare Facilities
- Plumbing Code Considerations
- · Preparing for Surveying a Healthcare Facility
- · Containment and Isolation
- Types of Processes Healthcare Facilities and How To Control Cross Connections

Types Health Care Facilities

- · Larae Hospitals
- · Long Term Care (LTC) Facilities
- · Laboratory Buildings
- Surgi-Centers
- · Cancer Centers
- · Office/Administration Support

3

Backflow Preventer-Selection Criteria

- 1. Evaluate Hazard Level of substance that could backflow - High/Health Hazard or Low Hazard?
- 2. Could backflow occur due to Backpressure, Backsiphonage, or BOTH?
- 3. Is "Continuous Pressure" resulting from a downstream shutoff or control valve possible (A/N)

Critical Concept



5



Survey Preparation/Considerations

- 1. Codes and Regulations Must know relevant codes. This was under IPC...
- 2. Containment vs. Isolation?
- 3. Point of use visual inspection vs. above ceiling tile/level?
- 4. Field Forms/Data Entry Process (i.e., how will you document field data?)
- 5. Ladders, equipment (considerations for inspecting pipe above tile)!





Survey Preparation/Considerations

- 6. Site Water Main and Architectural Drawings -Showing All Rooms, plumbing drawings, etc.
- 7. Meet with Personnel Familiar w/ Water Systems
- 8. PPE (eve protection, hearing protection, "Bunny Suits", face masks, etc).
- 9. Clarify Accessibility (master keys, permission, escorts, etc.)
- 10. Communication e.g., nurses on patient floors



- plus Main Hospital.
- Two- (2) separate community water supplies.
- Each supply controlled with reduced pressure principle backflow preventer (<u>Located in Pit!!!</u>). Each line combines to form a "Campus Loop"
- · Campus Loop supplies multiple campus buildings.



8

Containment Case Study - Questions

- Are all Campus Buildings supplied by Campus Loop? How does affect containment?
- 2. Is each building supplied by campus loop "contained"?
- 3. Are all domestic, fire and irrigation service connections accounted for/identified?



9



7

Containment Case Study - Findings


- 1. Are all Campus Buildings supplied by Campus Loop? How does affect containment? Cancer Center supplied directly from community water supplier – no containment.
- 2. Is each building supplied by campus loop "contained"? Not each building was contained many unprotected bypasses or no containment.
- 3. Are all domestic, fire and irrigation service connections accounted for/identified? Identified irrigation and fountain connections from campus loop - no protection.



11



12



Common Systems-Survey

Building Systems

- · Chilled Water
- · Boilers/Steam Generation
- Cooling Towers
- · Kitchen/Cafeteria Operations
- Lawn Irrigation
- · Decorative Fountains
- Humidification Systems Therapy Tubs/Cleaning

Medical Process Systems

- Morgue/Autopsy
- · Labs and Equipment
- Equipment Sterilization/Cleaning
- Dialysis Systems
- · Treated/Soft Water Systems
- Endoscopy Equipment
- Bed Pan Washers

13

Final CCC Survey Report Information

- Inventory of all backflow prevention assemblies, devices and methods
- Itemized list of **recommendations** based upon survey information – be specific in terms of location, system, etc.
- · Service connection assessment
- Internal Program Compliance, Local/State (Health Dept) or OSHA Compliance

and what do we need to do?

14

Domestic Hot Water Production

Use "Condenser Return Water" to Preheat Domestic Cold Water Before Supplying Heat Exchanger




15

Heat Exchangers Plumbing Code 608.16.3

Toxic Transfer Fluid = Double Wall Required Non Toxic Transfer Fluid = Single Wall Allowed



Preheat Domestic Cold Water For Domestic Hot Water Loop



17

Heat Exchangers MI Plumbing Code 608.16.3

- Must Evaluate Process Water Heat Exchanger
- Must Evaluate Steam/Domestic Hot Water Heat Exchanger
- ☐ Determine Toxicity of Transfer Fluid
- ☐ Determine HX Type Required (Single vs. Double Wall)

18



Domestic OR Process Hot Water?

- Must ensure correct labeling see picture...is this correct?
- Hot water line supplies sterilization equipment AND small restroom – compliant?
- Domestic hot water return lines must be **UPSTREAM** of backflow preventer supplying process water



THE SAFE WATER AUTHORITY.

19

Chemical Injection Systems - Air Gaps

- Common to see disinfectant introduction into potable cold and/or domestic hot water systems for bacteria control
- Typical disinfectant introduction (chlorine dioxide, hypochlorite, etc.)
- Air gaps on system drains required (AG=2X Diameter of Discharge Pipe, or 1" Minimum)



THE BATE WATER AUTHORITY

20

Chilled Water – RPBP Required
Typical Makeup – Chilled Water Return



THE SAFE WATER AUTHORITY.


21



THE SATE WATER AUTHORITY

22

Central Sterile Processing



THE BATE WATER AUTHORITY

23

Central Sterile Processing

- Many processes requiring water to process surgical instruments – all high hazard cross connections
- Ultrasonic Cleaners
- · Sinks w/ Spray Hoses
- · Chemical Dispensers
- Sterilization Equipment
- Autoclaves
- Deionized/RO Water
- These areas require special access and PPE.

THE SAFE WATER AUTHORITY.

0

24

Central Sterile Processing

- Typically dedicated cold and hot water mains are isolated with reduced pressure principle backflow preventers to "zone isolate" multiple processes
 - Practice requires strict/accurate pipe labeling
 - Often find other potable uses supplied by dedicated non-potable system!
 - · Often find processes not protected!

MUST WEAR THE BUNNY SUIT WHEN SURVEYING.....

THE BATE WATER AUTHORITY

25

Zone Isolation-Central Sterile

- RPBP in supply to cold and hot water
- Piping typically located above ceilingOften times find
- Often times find assemblies located above ceiling level/tile



THE BATE WATER AUTHORITY

26

Central Sterile – Sinks/Spray Stations



THE SATE WATER AUTHORITY

27

Autoclave – RPBP in Supply



THE BATE WATER AUTHORITY.

THE BATE WATER AUTHORITY

29

Central Sterile – Washer (RPBP Required)



SAFE WAISK AUTHORITY.

Sterilizers - RPBP in Supply



THE SAFE WATER AUTHORITY.

30

28

Endoscope Reprocessors

- ✓ May utilize cold and hot water mixed to supply equipment
- ✓ Water subsequently filtered
- √ Water used to reprocess endoscopes decontaminate between uses
- ✓ Commonly found Gastroentorology
- ✓ HIGH HAZARD CROSS CONNECTION RPBP typically required on cold and hot supply!!



Endoscope Reprocessors



32

RPBP in Supply Multiple Units



33

31

Astra Tee Transesophageal Reprocessor Found Commonly Ultra Sound Dept.





35

Deionized Water Systems

- Need deionized water for lab processing functions
- · Water may be heated for glass washing and supplying sterilizers
- Deionized water may be used to supply/makeup to clean steam, specific humidification operations, etc.
- Reduced pressure principle backflow preventer required – High Hazard cross connection!

DI System Supplied by Atmospheric Vacuum Breaker – Inappropriate Device



36



Dialysis Treatment

- Centralized multistep water treatment system to supply product water loop
- Wall hydrants to connect dialysis treatment units to treated loop
- RPBP in potable cold and domestic hot water supply
- · High Hazard!



38

Dialysis Cart and Wall Connection





39

Dental Operations/Lab

- · Dental Chairs water supply vs. bottle water supply
- Grinder systems
- Vacuum systems
- Lab faucets

40





- RPBP in cold supply and also in supply to dedicated domestic hot water heat exchanger
- Dedicated cold and hot water lines supply morgue operations
- Discharge lines also supply public restroom is this acceptable????



Embalming Station Supply

• RPBP in main supply





42

"SAF T" Pumps

- Disposal of infectious liquid medical waste
- Potable water flows through venturi – aspirating dangerous fluids to waste stream (High Hazard!)
- Reduced pressure principle backflow prevention assembly
- Commonly found Operating Room areas
- Must review drainage of RPBP



"Macerator"

- Disposal of bedpan pulp materials and waste
- Machine pulverizes materials with addition of water to facilitate decomposition and drainage
- Water typically flows from top of lid
- RPBP may be recommended water supply is typically threaded hose connection from behind unit



THE BATE WATER AUTHORITY

44

Dethawer – Blood Bank/Lab

- Bath to warm up frozen blood samples
- Typically supplied water by hose drop
- Approved vacuum breaker required



THE SAFE WATER ADTHOUTT

45

43

Blood Bank – Equipment Drain (Waste Dilution)

- Multiple system drains and drain trap primers may be found in lab areas.
- Approved air gap must be equivalent of 2X diameter of outlet pipe.



Bed Pan Washer/Slop Hopper

- Approved vacuum breaker for spray hose must be installed per Plumbing Code (IE: 6' above floor)
- Inspect for valves at end of spray hose (implies possible continuous pressure)
- AVB or SVB (continuous pressurevalve) required
 Often installed adjacent to
- Often installed adjacent to chemical dispenser (inspect for vacuum breaker, wasting tee)



THE SAFE WATER AUTHORIT

Shower Heads/Hoses

- Shower hose may be "air gapped"
- Showers may have atmospheric vacuum breaker in supply
- Some showers may have Watts S8C or equivalent in supply
- ASME A112.18.1 or ASME
 A112.18.3



THE SAFE WATER AUTHORITY

47 48

46

Ice Machines

Inspection Items

- ✓ Found throughout patient floors, kitchens, therapy areas
 ✓ Internal air gap or ASSE 1022
- ✓ Internal air gap or ASSE 1022 required in water supply to ice maker
- ✓ Approved air gap required for water cooled condenser - drain line
- √ Water supply filters commonly have drain line – approved air gap required



THE SAFE WATER AUTHORITY.

49

Commercial Laundry Machines RPBP Required Cold and Hot Supplies



THE BATE WATER AUTHORITY

50

Decorative Fountains

- High Hazard Cross Connection!
- Chemical treatment, exposure, bacterial growth, etc.
- Many hospitals are decommissioning due to Legionella concerns



51

Decorative Fountains – Typical System Makeup



THE SAFE WATER AUTHORITY.

52

Approved?

- Double Check Valve Assembly (Low Hazard Assembly) in Supply to Fountain
- Reduced Pressure Principle
 Backflow Prevention
 Assembly Required!



THE SAFE WATER AUTHORITY.

53

Water Wall



THE BATE WATER AUTHORITY.

54

Decorative Fountain – Supplied Reclaimed Water



55

Indoor Decorative Fountain-Manual Fill



56



 Sealing water may be once pass through (high water use), or recirculated/cooled to perform seal via a heat exchanger/chilled water (reduce water makeup)

• Reduced pressure principle backflow preventer typically required



57

Potable Water Line-Backup Supply to Vacuum System – Approved?




· Steam-humification common

 Remote water supplied units commonly found in OR and MRI areas

- · Must inspect internal makeup and drain from system for approved air
- gap


 Multiple systems typically recommend RPBP in supply
- · Picture what's wrong???



59

Steam Humification Unit

 Reduced pressure principle backflow preventer in cold water supply



60

Emergency Room Decontamination Showers

- Showers for Decontamination
- Typical Hot and Cold Water routed to SVB
 Must review "Critical Level" of Spill Resistant Vacuum Breaker in relation to highest point of hose



THE SAFE WATER AUTHORITY.

61

Outdoor Multiple
Decontamination Showers



THE SAFE WATER AUTHORITY.

62

Janitor Sinks – Soap Dispenser Why Is This a Non-Compliant Installation?

- Valve is downstream of AVB at splitter and inside unit soap dispenser. AVB cannot have valve downstream.
- Hose is elevated AVB cannot be subject to backpressure.
- AVB can fail allowing chemical to backflow into potable water supply, or allowing domestic hot water to flow into cold supply.





THE SATE WATER AUTHORITY

63

SOLUTION: Install Water Wasting Tee

- Forces user to shut off water supply after mixing soap and water, allowing water to drain from hose via "Wasting Tee".
- Shutting off water supply and allowing for hose drainage prevents "continuous pressure" and "backpressure" on AVB.
- Protects AVB and allows it to function properly.

THE SAFE WATER AUTHORITY.





65

Water/Steam Cleaning Station



THE SAFE WATER AUTHORITY

66

RPBP – Condensate Makeup Tank Supply – Location, Location, Location...



Domestic Water Backup – Condensate Tank – Taken From Catwalk



THE SATE WATER AUTHORITY.

68

Chilled Water Makeup w/ RPBP Bypass Connected to Strainer!



69

67



Oops.....lawn irrigation system supply





71 72

CCC - Best Management Practices

Develop Cross Connection Control Plan

1. Containment/Isolation Policy

Preventers

- 2. Survey Requirements (i.e., how often)
- Backflow Prevention Assembly Testing
 Required and Approved Backflow
- 5. Recordkeeping/Data Management

CCC Plan/Program may also support efforts in Legionella WMP!







73

E SAFE WATER AUTHORITY.

Legionella WMP/Best Practices


- Perform an in-field assessment of building water systems for Legionella risk to include evaluating water equipment, cross connections, dead legs, plumbing materials, etc.
- Develop a Legionella Water
 Management Plan
- Maintain accurate data management/records, training, system drawings/information



THE SATE WATER AUTHORITY.

74

Process Flow Diagram Sample



75

Further Information



Steve Fox sfoxs@hydrocorpinc.com 301-741-7093 HydroCorp 5700 Crooks Road, Suite 100 Troy, MI 48098 800.690.6651 | hydrocorpinc.com

THE SAFE WATER AUTHORITY

76